



VOLVO - continued

engs. B27A, B27E, B27F USA, B28A B28F USA	9/78→	240	HK8408●	HE2504	HB8123●	HD1227
eng. B28E	9/78→	240	HK8409●	HE3901	HB8123●	HD1227
engs. Turbo B19ET, B21ET	81-8/84	215	--	--	HB3858 HB8044●	HD1021
	9/84→	215	--	--	HB3858 HB8044	HD5537
eng. B21A (M47 gearbox)	83-8/84	228	HK5590 HK9069●	HE5001	HB3858 HB8044	HD1021
engs. B200E, B200K (M47 gearbox)	9/84→	228	HK5591 HK9189●	HE5001	HB3858 HB8044●	HD5537
eng. B23A (M47 gearbox)	83-8/84	228	HK419●	HE5001	HB9418●	HD1021
eng B23F USA	82-8/84	215	--	HE5132 ¹	--	HD1219 ¹
engs. B230A,K (M45 gearbox) B230A,E,F,K (M47 gearbox) B230F USA (M47 gearbox) B230A,E,F,K (M46 gearbox)	9/84→	228	HK9420●	HE5001	HB9418●	HD5537
	9/86→					
262 engs B27A, B27E, B27F USA (M45 & M46 gearbox) B27A, B27E, B27F USA B28A, B28F USA	74-8/78	240	HK8408●	HE2504	HB8123●	HD1227
	9/78→					
eng. B28E	9/78→	240	HK8409●	HE3901	HB8123●	HD1227
264 engs. B27A, B27E, B27F USA (M45 & M46 gearbox)	74-8/78	240	--	HE2504	--	HD1227
engs. B27A, B27E, B28A, B27F USA B28F USA	9/78→	240	HK8408●	HE2504	HB8123●	HD1227
eng. B28E	9/78	240	HK8409●	HE3901	HB8123●	HD1227
eng. B21F USA	9/78-8/84	215	HK5157 HK8138●	HE5132 ¹	HB3858 HB8044●	HD1219 ¹
eng. B27E (M50 & M51 gearbox)	74-8/78	240	HK9202	HE2504	HB8774●	HD1227
eng. B23A (M45 & M46 gearbox)	8/79-8/84	215	HK5157 HK8138●	HE5132 ¹	HB3858 HB8044●	HD1219 ¹

NOTE: ¹Cover assembly HE5132 and Release bearing HD1219 must always be used as a set.